

MALONEY TECHNICAL PRODUCTS

LineMRKR™ INSTALLATION INSTRUCTIONS

Scope:

This procedure is designed to provide guidelines for the proper installation of the Maloney LineMRKR™ or Test Station assembly. The actual condition of the ground and local regulations may supersede the following recommendations.

Procedure:

1. Check that the assembly is complete. Each unit should consist of a molded cap or test station, riveted to a post, and an anchor tube.
2. Select an installation site from which the marker will be visible from the previously installed post. Line of site visibility is a requirement of the applicable DOT regulations. Utility installations may have different requirements.
3. Using a post hole digger or auger, dig a hole approximately 6-7" in diameter a minimum of 18" deep. Soft ground conditions may require greater hole depth to provide secure installation.
4. Insert the anchor tube into the cross-hole at the base of the post. Place the assembly upright into the previously prepared hole and backfill with dirt.
5. Support the post as close to perpendicular to the ground as possible and tamp down the backfill until the post is secure.